

**F4**

—

**20**

Contact auxiliaire

Contacts	
20	2NO
11	1NO+1NF
02	2NF
40	4NO
31	3NO+1NF
22	2NO+2NF
13	1NO+3NF
04	4NF

